

## Afi S Winter Cover assembling instructions

1. Check that all parts have arrived with no damage.
2. Each winter cover should include the follows items:
  - a. 1 main 3 walls cover
  - b. 2 snap corners (for Breeze S3 only)
  - c. 2 Velcro strips (1"x 6.23 ft each)
  - d. 50 washers
  - e. 50 screws
  - f. 1.5 meter of adhesive Velcro (3/4" width)
3. Secure the 2 identical Velcro strips (1"x 6.23 ft each) to the canopy top arcs, Start from the rear so that the 2 cut Velcro are at the rear (see below picture).



4. The strips are identical for Left and Right.
5. This way all the premade holes will fit all along the arc's holes.
6. Secure in each side all the 23 holes, each with screw and washer, 23 at each side (see below picture).



7. After finish assembling the 2 strips, assemble the main 3 winter cover (3 walls) onto place.
8. Fix the 6 Velcro bands at the rear to the canopy rear pipes.
9. Fix the cover Velcro long arcs to the Velcro strips that you have just secured.
10. The winter cover now is on place.
11. Cut 10 pieces of the adhesive Velcro (3/4" width), ~5" each.
12. Fix them to the follows places on the scooter covers:

- a. Adhere 2 at the rear side of the cover at the top and at the bottom (see below picture).



- b. Adhere 2/4 along the fenders / battery cover (see below picture).



- c. Adhere 2 at the front edge of the side bumper, .1 each side (see below picture). (It may be needed to help the adhesive with extra glue or screws.)



Now the winter cover is ready for use.

- d. If the adhesive Velcro (3/4" width) needs more securing to the scooter covers, extra secure screws can be used.

### Winter cover Main Functions:

13. To open and close the door, use the front-bottom Zipper.

14. To open a vent window, use the rear top Zipper. Open it partially forward.



15. To drive with open doors on warm days, open the front zipper all to the back.

Flap each door halfway up with the Velcro and again flap to the back of the seat and quick snap it there.