



| No. | Code          | Description                       |
|-----|---------------|-----------------------------------|
| 1   | S12-067-00100 | Speed Dial Ass'y (Envoy)          |
| 2   | S02-067-00100 | Tiller Swivel Ass'y (Envoy)       |
| 3   | S02-067-00200 | Delta Tiller Ass'y (Envoy)        |
| 4   | S08-067-00100 | Cover, Handle Bar Ass'y (Envoy)   |
| 5   | S08-067-00300 | Shroud, Tiller Front (Envoy)      |
| 6   | S08-067-00400 | Shroud, Tiller Rear (Envoy)       |
| 7   | S10-067-00100 | PG S-Drive 70A Controller         |
| 8   | S34-067-00100 | Velcro Strip Set, Battery (Envoy) |
| 9   | S08-067-00200 | Shroud, Front (Envoy)             |
| 10  | S08-067-00500 | Shroud, Footrest Ass'y (Envoy)    |
| 11  | S08-067-00600 | Shroud, Rear (Envoy)              |
| 12  | S02-001-00601 | Regular Bearing Ball Set (Envoy)  |
| 13  | S01-067-00100 | Front Bumper Ass'y (Envoy)        |
| 14  | S04-067-00100 | Shock Absorber, 250lb (Envoy)     |
| 15  | S13-067-00100 | Headlight Ass'y (Envoy)           |

| No. | Code          | Description                     |
|-----|---------------|---------------------------------|
| 17  | S01-067-00200 | Frame, Front Section (Envoy)    |
| 18  | S01-067-00300 | Frame, Rear Section (Envoy)     |
| 19  | S09-067-00100 | Transaxle Ass'y, 4mph (Envoy)   |
| 20  | S03-039-00400 | Front Fork Ass'y (Envoy)        |
| 21  | S05-040-00300 | Front wheel w. solid tyre 285mm |
| 22  | S03-033-00400 | Connecting Rod Ass'y (Envoy)    |
| 23  | S03-067-00100 | L Type Steering Axle (Envoy)    |
| 24  | S06-040-00300 | Rear wheel w. solid tyre 285mm  |
| 26  | S07-067-00100 | Armrest Ass'y (Envoy)           |
| 27  | S07-067-00300 | Seat Post Set (Envoy)           |
| 28  | S18-067-00200 | Wire Harness Ass'y (Envoy)      |
| 29  | S08-067-01718 | Shroud Set, Red (Envoy)         |
|     | S08-067-01754 | Shroud Set, Blue (Envoy)        |
|     | S08-067-01777 | Shroud Set, Graphite G. (Envoy) |
|     | S08-067-01791 | Shroud Set, White (Envoy)       |

Separate Components Available:

**From the Motor & Transaxle Ass'y (S09-062-00100):**

- C09-067-00200 (Transaxle, Envoy 4)
- C09-067-00400 (EM Brake, Envoy 4)
- C09-001-10101 (Motor, 350W)
- C09-005-00601 (Carbon Brush, 7x17mm)
- 9357005005035 (Keyway)

**Wiring Looms**

- C18-067-00101 (Main loom, Envoy 4)
- C16-022-00402 (30A Circuit Breaker)
- C18-001-10302 (Battery Cable – Fused)
- C18-001-10402 (Battery Cable – Unfused)
- C18-067-00400 (Power Cable to Controller)

**Other Electrical Parts**

- C18-001-01501 (Ignition Switch)
- C12-001-10202 (Charger Socket)
- C11-045-00102 (Battery Gauge)
- C11-001-00700 (Speed Pot)
- C16-001-10500 (Headlamp Switch)
- C16-001-10500 (Horn Switch)

